



## PHOSCRETE PATCH KIT INSTRUCTIONS

<p><b>1. It's FAST!</b> so have all your tools and PPE ready:</p> <ul style="list-style-type: none"><li>• <i>Gloves &amp; Safety Glasses</i></li><li>• <i>Plastic Mixing Stick (or Margin Trowel)</i></li><li>• <i>Water and Cloth Towel for cleanup</i></li></ul>	<p><b>2. Prepare</b> your repair location by removing damaged concrete and oils. Use a chisel and/or a wire brush.</p> <ul style="list-style-type: none"><li>• <i>Surface must be completely dry.</i></li><li>• <i>Blow off any dust.</i></li></ul>
<p><b>3. Remove Contents from Patch Kit Tub:</b></p> <ul style="list-style-type: none"><li>• <i>Liquid Jar</i></li><li>• <i>Dry Mix Bag</i></li><li>• <i>Mixing Stick</i></li></ul>	<p><b>4. FIRST:</b> Empty Activator Jar into Tub. <b>NEXT:</b> Empty Dry Mix Bag into Tub.</p>
<p><b>5. Mix well</b> with enclosed stick until Dry Mix and Activator are fully blended (about 30 seconds)</p>	<p><b>6. Lightly Dampen Gloves</b>, and shake off excess water. Scrub a small amount of Phoscrete to coat the surface of the repair site.</p>
<p><b>7. Wait 30 Seconds</b> for the scrub coat to stick, then lightly dampen gloves again press more Phoscrete to fill repair site.</p>	<p><b>8. Finish</b> using the mixing stick or trowel. Wipe tools clean with a damp towel when finishing.</p>
<p><b>9. Use a Stucco Sponge</b> (lightly dampened) to achieve a smooth finish to your repair.</p>	<p><b>10. Clean tools and gloves with water.</b> Wash hands with soap and water when finished.</p>

*Use water sparingly and only to keep Phoscrete from sticking to tools and gloves.*

*To extend working time, Phoscrete Tubs can be chilled below 0°F in a freezer.  
The colder the material, the longer your working time (from 5 to 30 minutes)*

**Phoscrete will be completely hardened in less than one hour!**

If you have questions, please do not hesitate to contact your local Phoscrete representative or call our corporate offices for application assistance.